## **Suction Plates ESP**

Туре	Suction Plate Dimension in (mm)	Working Load Limit WLL** lbs (kg)	Order-Number
ESP-85-25,5/25,5	10" x 10" (255 x 255)	185 (85)*	42100051
ESP-150-31/31	12 <sup>1</sup> / <sub>4</sub> " x 12 <sup>1</sup> / <sub>4</sub> " (310 x 310)	333 (150)*	42100145
ESP-200-33/33	13" x 13" (330 x 330)	440 (200)*	42100331

## ESP-150-31/31



## Lifting Hose Units HE

For use with the Jumbo Travelling Crane JWK, the JUMBOMOBIL JM or on any other crane carrier. (Application of lifting hose unit HE-250 is permissible at stationary crane facilities only, not to be operated with JUMBOMOBIL, JUMBO-BV and Jumbo Travelling Crane JWK). Consists of:

- Rotational Device and quick coupling, 2 inch
- Lifting hose unit with protective fabric as well as a flange for fitting onto the operating valve unit
- Available optionally for HE-150/200/250: reinforced belt stay with buckle

Туре	Working Load Limit WLL*** lbs (kg)	Diameter Lifting Hose in (mm)	Lifting Height in (mm)	Order- Number
HE-150	330 (150) *	9 (230)	59 (1,500)	42100132
HE-200	440 (200) *	9¾" (250)	59 (1,500)	42101114

## **Operating Valve Unit BE-Sprint-2**

- For direct coupling onto the lifting unit HE
- Consists of: Main body with handle 500 mm long, fixing screw for adjusting the hovering position, safety gauge

Туре	For use with	Order-Number
BE-Sprint-2	HE-35 up to HE-250	42100539





\*\* Caution: It is forbidden to use suction plates with a smaller carrying capacity than the lifting unit HE! It is permissible to use suction plates with a higher carrying capacity than the lifting unit.

- \* Value at 420 mbar low pressure
- \*\*\* Caution: Take note of the working load limit of the crane equipment